



## **SPRING-ASSIST TORQUE HINGE**

71-7-3911

The built-in spring makes lids feel lighter to open (the hinge is for top-opening lids). The retaining torque is adjustable with a hex key (0 to 3.5 N.m). Cycling resistance: 50,000 cycles. Operating temperature:  $0^{\circ}/+40^{\circ}$ C.

The hinge is delivered with a pin attached. It keeps the hinge open. Please do not detach until the hinge is installed. Optional cover is sold separately (22-7-3556).

100

<del>2</del>0

12

Ш







