



MAGNETIC TOUCH LATCH

16-7-4331

Lightly push to open the door.

When closing, magnet will catch the door by lightly pushing.

For overlay doors, make a 3.5mm gap between door and cabinet frame.

Body: ABS

Counter plate and yoke: steel zinc chromate

Included:

- Counter plate
- 4 round head wood screws 3.1 x 13 mm
- 1 countersunk head screw 2.7 x 13 mm.

A	43.5 mm
Material	ABS
Weight (g)	22 g
B	36 mm
C	15 mm
Finish	white
Nouvelle référence	NEW

